

FZ/MT 07 SUBCAGE/12BAR

INSTALLATION GUIDE



First remove the brake reservoir from the right side passenger pegs. Keep the bracket as it will be reused later on.



Remove the passenger pegs from both sides of the bike.



Next Remove the 4 bottom push rivets from underneath the fender.



Hold the fairings to the side to access the bolts under neath the fender.

* The rear light wire must be disconnected to remove the fender *



Take the adapter plate and hardware provided. Install underneath the fender with the nut facing down.

Once installed put the side fairings back and reinstall the rivets.



Take the sub cage and lightly bolt up the front tabs to the passenger peg mounts.

The brake tab will fit over the sub cage tab.

Take the OEM reservoir bolt we removed in the first step to and bolt up the reservoir.



Take the 5/8s bolt and bolt up the rear subcage to the adapter plate.

If installing the license plate bracket. Place bracket in between the subcage and bolt as shown.



Install the pegs to the subcage with the hardware provided.

Secure the slider with the set screw.



If purchased install the titanium and step plate to the rear end of the subcage.

Lastly tighten all bolts to specs.

TORQUE SPECS			
LOCATION	SIZE	N●m	Lb-ft
REAR FENDER	M6	19	14.5
FRONT SUBCAGE	M8	47	35
PEGS	M10	95	70